

### FILTRATION | SEPARATION | PURIFICATION



### **Product Specifications**

Media: Borosilicate Microfiberglass

with Acrylic Binder

Inner Core: Polyester
Support Layers: Polyester

Cage, End Caps: Polyester

Gaskets/O-Rings:

Buna-N, EPDM, Silicone, Teflon Encapsulated Viton (O-Rings only),

Teflon (gaskets), Viton

Micron rating:

0.2, 1, 10, 30 μm

#### **Dimensions**

### **Nominal lengths:**

5", 9.75", 10", 19.5", 20", 29.25", 30", 39", 40" (12.7, 24.8, 25.4, 49.5, 50.8, 74.3, 76.2,

99.1, 101.6 cm)

Outside diameter: 2.7" (6.86 cm)
Inside diameter: 1.0" (2.54 cm)

### **Operating Parameters**

Maximum operating

temperature: 230°F (110°C)

Maximum differential pressure:

75 psid @ 70°F (5.2 bar @ 21°C)

60 psid @ 200°F (4.1 bar @ 93°C)

50 psid @ 230°F (3.4 bar @ 110°C)

Maximum reverse pressure:

40 psid @ 70°F (2.8 bar @ 21°C)

Recommended change-out pressure:

35 psid (2.4 bar)

# **GFP™ Series Filter Cartridges**

## High Temperature Glass Fiber Cartridges

This high efficiency, economical filter element is constructed of pleated Borosilicate Microfiberglass media that combines excellent flow rates with exceptional service life. The polyester supports of the GFP filter cartridge provide enhanced thermal tolerance for applications for higher temperature applications. The nominally-rated borosilicate microfiber depth matrix has a natural positive charge that aids in the retention of negatively charged particulates and combined with the depth characteristics of glass media, works well in the removal of both deformable and non-deformable particles. The GFP filter cartridge is an economical solution for both liquids and gases in a wide variety of filtration applications.

### **FEATURES & BENEFITS**


- Polyester hardware extends application range beyond the limits of polypropylene.
- Higher temperature capability of 230°F (110°C)
- Micron ratings from 0.2 to 30 μm Broad application range
- Uniform pore size High removal efficiency
- High surface area High flow capability and dirt holding capacity
- · Long service life Minimizes maintenance costs
- Fixed pore construction Eliminates dirt unloading at maximum differential pressure

### TYPICAL APPLICATIONS

- Petrochemicals
- Chemicals
- Solvents
- Inks
- Oil & Gas
- · Lube Oil

GFP NOMENCLATURE INFORMATION										
Filter Type	Retention Rating (microns)	Nominal Length (inches)		End Configuration			Gasket or O-Ring			
GFP	0.2	-5	-29.25 <sup>*</sup>	Р	Double Open End	В	Buna-N			
Series	1	-9 <b>.</b> 75*	-30	P2	226/Flat Single Open End	Е	EPDM			
	10	-10	-39 <sup>*</sup>	Р3	222/Flat Single Open End	S	Silicone			
	30	-19.5* -20	-40	P7	226/Fin Single Open End 222/Fin Single Open End	Т	Teflon encap. Viton (O-Rings only)			
				P8						
						Т	Teflon Gasket			
Example: GFP 1–10P3B						V	Viton			
GFP	1	-10		P3		В				

<sup>\*</sup>Available only for DOE (P) configuration



REMOVAL EFFICIENCY										
Beta Ratio Efficiency	Beta 10 90%	Beta 20 95%	Beta 100 99%	Beta 1000 99.9%	Beta 5000 99.98%					
0.2 μm	0.2	0.3	0.6	0.8	1.0					
1 μm	1.0	1.3	2.0	3.5	4.0					
10 μm	10.0	12.0	15.0	17.0	18.0					
30 μm	30.0	35.0	38.0	42.0	45.0					

Beta Ratio = 
$$\frac{\text{Upstream particle counts}}{\text{Downstream particle counts}}$$

The micron ratings shown at various efficiency and beta ratio value levels were determined through laboratory testing, and can be used as a guide for selecting cartridges and estimating their performance. Under actual field conditions, results may vary somewhat from the values shown due to the variability of filtration parameters.

Testing was conducted using the single-pass test method, water at 2.5 gpm/10" cartridge. Contaminants included latex beads, coarse and fine test dust. Removal efficiencies were determined using dual laser source particle counters.

### FOR MORE INFORMATION

GTX-318 4-21

**DISTRIBUTED BY** 

Customer Service/Technical Support: 1-888-353-0303 Europe (UK): +44-1424-777791 | China: +86-21-5238-6576 Asia: +65 9671 9966



All information and recommendations appearing in this bulletin concerning the use of products described herein are based on tests believe to be reliable. However, It is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Graver Technologies as to the effects of such use or the results to be obtained. Graver Technologies assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government regulations. GFP is a trademark of Graver Technologies. LLC.

